



## **L200 Series 6 - 2019 On**

NLG Black Roof Rail Set

Fitting Instructions

Part Number: L200-19RRBLACK#



## Fitting Kit



2x M8x40mm Cap screws

2x M8x50mm Cap Screws

4x M8 Connection Bolts

4x M8 Washers

4x Plastic Caps

## Tools Required

6mm Hex Key

## Installation Instruction

Remove rubber strips from both roof channels and put to one side. It is optional if you want to refit these strips during the installation. If strips are not required then discard.



In the channel of the roof you will find mounting points as per image below.



Offer up a roof rail to the vehicle and make note of which two mounting points will be used during the installation of the bars on each side. Take the supplied M8 connection bolts and insert into the noted mounting points on both sides of the vehicle as shown in the image.



At this point you can choose to reinstall the trim plastic making sure to cut at the points of the four connection bolts. Once trim has been replaced or discarded and making sure each of the feet of the roof rails have a rubber gasket. Place the bars onto the vehicle so the previously fitted connection bolts should now sit inside the roof rails.



Take the supplied M8x40mm cap screws with an M8 washer and use these to secure the front feet of the roof rails into the connection bolts. Take the M8x50mm cap screws with an M8 washer and secure the middle feet of the roof rails into the connection bolts.

Once secure to the vehicle use the plastic caps to cover the holes the cap screws were inserted into.

