

## WR01-FITTINGKIT

### **Step 1.**

Unscrew ariel. Remove fittings from the underside of roof rails, Torx T30 bit required (not supplied) Two fittings front & two fittings rear. *(Please note, roof rails do not need to be removed from vehicle)*



### **Step 2.**

Replace with fittings provided (Item 7 on fitting kit diagram) these are to be fitted by screwing a couple of threads in only at this stage – as shown below. **(Thread locker advised on these fittings)**



### **Step 3.**

Place platform rack upside down on an even protected surface. Insert T-slot bolt into recess where the plastic joining piece joins the rack together (length ways).

Insert at a 45-degree angle and then horizontal to insert. T-slot bolt will now slide in either direction, push two into one half of the rack, and 2 into the other half – repeat for other side.



#### **Step 4.**

Use drawing diagram to determine which bracket will fit in which corner of platform rack,

Note that the platform rack has a 'Predator' logo badge on the front of rack & brackets with 'Predator' logo cut into them also fit at the front of vehicle.

Fit Nylon lock nuts a couple of threads only so that brackets can be tilted backwards as shown below.



#### **Step 5.**

Fit all brackets loosely as shown. (Brackets have fallen inwards as they are not being held outwards in this image)





**Step 6. (Minimum of 2 persons required)**

Whilst holding the brackets outwards, so that brackets fall over the outside of roof rail, lower the platform rack & brackets over one roof rail at a time (do not try to lower over both rails at the same time)

Once brackets have been lowered down the outside of rail, tilt the brackets and slide underneath the rail ensuring fittings slide between the slotted holes in the brackets. Once brackets are loosely in place, screw fittings into roof rail a couple more threads.

The same procedure applies for the rear brackets as the front brackets.

Repeat procedure for other side of vehicle.



Once all for mounting brackets have been aligned with fittings on underside of roof rails, tighten but not fully tighten all fittings so that brackets and roof rack can slide for adjustment.



### **Step 7**

Position platform rack into final desired position, (rack will move from side to side and front to back) and tighten all fixtures and fittings.

Please note – if you wish to re fit OEM ariel, a hole is required to be drilled in the platform rack to allow for this.